

WATERGUARD PULSE SPLITTER - TECHNICAL INFORMATION & INSTALLATION INSTRUCTIONS



These instructions should be used in conjunction with the Waterguard Series 7 Installation Guide.

DIN rail application includes:

- The Waterguard water meter pulse splitter, where the output from a water meter is shared with another device, (Building Management System, BMS)
- The Waterguard 12VDC power supply for one or more pulse splitters and or other devices requiring 12VDC 1 Amp supply

